

Safety-Grip application instructions – our video application instructions are available at [www.heskins.com/nonslipvideos.html](http://www.heskins.com/nonslipvideos.html)

Safety-Grip always provides an anti-slip surface that is:

- ✓ Durable
- ✓ Efficient
- ✓ Effective

But for best results follow the instructions below to ensure maximum performance in all environments.

### 1) Material Storage

Ensure the material is kept in dry, warm conditions in the original protective packaging.

### 2) Surface Preparation

A clean, dry surface is essential. Use an IPA cleaner to remove all surface contaminants (paint flakes, etc) – DO NOT use methylated spirits/petrol/lighter fluid etc as these leave behind a thin, greasy residue. Ensure prepared surface is above 10°C.

### 3) Porous Surface Sealing

Porous surfaces must be sealed prior to application to prevent water attacking the adhesive. Toluene based primers are ideal - we recommend our own product for this job. Apply a thin coat to the cleaned surface using a paint brush, then leave to dry.

### 4) Tape Application

Peel back part of the release liner then press the adhesive firmly onto the prepared surface, and slowly keep peeling back the liner while applying the tape. Try to ensure that the tape is not taut.

### 5) Finish!

Once applied, press tape down firmly using even pressure (decorating rollers are excellent for this). We recommend sealing the edges using 'edge fix' as this will extend the life of the product. Only use a small amount down the edges, a thin bead.

If correctly applied, the new anti-slip surface can be walked on instantly, you will get maximum benefit from the adhesive system after 48 hours.

